

Specifications for PIXMA E460



Print		
Maximum Printing Resolution	4800 (horizontal)* ¹ x 600 (vertical) dpi	
Print Head / Ink	Number of Nozzles:	Total 1,280 nozzles
	Ink Droplet Size (minimum):	2pl
	Ink Tank:	PG-47, CL-57
Print Speed Based on ISO / IEC 24734. Click here for summary report Click here for Document Print and Copy Speed Measurement Conditions	Document: Colour* ² : ESAT / Simplex:	Approx. 4.0ipm
	Document: B/W* ² : ESAT / Simplex:	Approx. 8.0ipm
Printable Width	Bordered:	Up to 203.2mm (8-inch)
Printable Area	Bordered Printing:	Top margin: 3mm, Bottom margin: 16.7mm, Left / Right margin: each 3.4mm (Letter / Legal: Left: 6.4mm, Right: 6.3mm)
Recommended Printing Area	Top Margin:	31.6mm
	Bottom Margin:	29.2mm
Paper Size	A4, A5, B5, Letter, Legal, 4 x 6", 5 x 7", Envelopes (DL,	

	COM10), Custom Size (width 101.6 - 215.9mm, length 152.4 - 676mm)	
Paper Handling (Rear Tray) (Maximum Number)	Plain Paper	A4, A5, B5, Letter = 60, Legal = 10
	Photo Paper Plus Glossy II (PP-201)	4 x 6" = 20
	Photo Paper "Everyday Use" (GP-601)	4 x 6" = 20
	Envelope	European DL / US Com. #10 = 5
Paper Weight	Rear Tray:	Plain Paper: 64 - 105g/m ² , Canon specialty paper: max paper weight: approx. 275g/m ² [Photo Paper Plus Glossy II (PP-201)]
Scan * ⁴		
Scanner Type	Flatbed	
Scanning Method	CIS (Contact Image Sensor)	
Optical Resolution* ⁵	600 x 2400dpi	
Selectable Resolution* ⁶	25 - 19200dpi	
Scanning Bit Depth (Input / Output)	Grayscale:	16 bits / 8 bits
	Colour:	48 bits / 24 bits (RGB each 16 bits / 8 bits)
Line Scanning Speed* ⁷	Grayscale:	1.2ms/line (300dpi)
	Colour:	3.5ms/line (300dpi)
Scanning Speed* ⁸	Reflective: A4 Colour / 300dpi	14secs.
Maximum Document Size	Flatbed:	A4 / Letter (216 x 297mm)
Copy		
Maximum Document Size	A4 / LTR (216 x 297mm)* ⁹	
Compatible Media	Size:	A4, Letter
	Type:	Plain Paper
Image Quality	Plain Paper: Fast, Standard	

Copy Speed* ¹⁰ Based on ISO / IEC 29183. Click here for summary report Click here for Document Print and Copy Speed Measurement Conditions	Document: Colour: sFCOT / Simplex:	31secs.
	Document: Colour: sESAT / Simplex:	1.6ipm
Multiple Copy	Black / Colour:	1 - 21 pages
Network		
Protocol	TCP/IP	
Wireless LAN	Network Type:	IEEE802.11n / IEEE802.11g / IEEE802.11b (infrastructure mode)
	Frequency Band:	2.4GHz
	Range:	Indoor 50m (depends on the transmission speed and conditions)
	Security:	WEP64 / 128bit, WPA- PSK (TKIP / AES), WPA2-PSK (TKIP / AES)
System Requirements (Please visit www.canon-asia.com to check OS compatibility and to download the latest driver updates.)	Windows:	Windows 8 (32 / 64bit) / Windows 7 (32 / 64bit) / Window Vista (32 / 64bit) / Windows XP (32 / 64bit)
	Macintosh:	Mac OS X v10.6.8 or later
General		
Interface	USB 2.0 Hi-Speed	
Google Cloud Print	Available	
PictBridge	Wireless LAN:	Available
PIXMA Cloud Link	From smartphone or tablet:	Available
	From printer:	Available
PIXMA Printing Solutions	Available	
Access Point Mode	Available	
Operating Environment* ¹¹	Temperature:	5 - 35°C
	Humidity:	10 - 90% RH

		(no dew condensation)
Recommended Environment * ¹²	Temperature:	15 - 30°C
	Humidity:	10 - 80% RH (no dew condensation)
Storage Environment	Temperature:	0 - 40°C
	Humidity:	5 - 95% RH (no dew condensation)
Acoustic Noise (PC Print)	Photo (4 x 6")* ¹³	Approx. 46.5dB(A)
Power	AC 100 - 240V, 50 / 60Hz	
Power Consumption	Standby (scanning lamp is off) (USB connection to PC):	Approx. 1.6W
	OFF:	Approx. 0.3W
	Copying* ¹⁴ : (USB connection to PC)	Approx. 11W
Environment	Regulation:	RoHS (EU, China), WEEE (EU)
	Eco-Label:	Energy Star, EPEAT
Dimension (W x D x H)	Approx. 426 x 306 x 145mm	
Weight	Approx. 3.5kg	

Specifications are subject to change without notice.

- *¹ Ink droplets can be placed with a pitch of 1/9600 inch at minimum.
- *² Document print speeds are the averages of ESAT in Office Category Test for the default simplex mode, ISO / IEC 24734. Photo print speed is based on the default setting using ISO / JIS-SCID N2 on Photo Paper Plus Glossy II and does not take into account data processing time on host computer. Print speed may vary depending on system configuration, interface, software, document complexity, print mode, page coverage, type of paper used etc.
- *³ Paper types NOT supported for borderless printing are as follows: Envelope, High Resolution Paper, T-Shirt Transfer, Photo Stickers.
- *⁴ TWAIN driver (ScanGear) is based on the TWAIN specification V1.9 and requires the Data Source Manager comes with the operating system.
- *⁵ Optical resolution is a measure of maximum hardware sampling resolution, based on ISO 14473 standard.
- *⁶ Increasing the scanning resolution will limit the maximum possible scanning area.
- *⁷ The fastest speed in Hi-Speed USB on Windows PC. Transfer time to computer is not included.
- *⁸ Colour document scan speed is measured with ISO / IEC 29183 Target A. Scan speed indicates the time measured between pressing the scan button of the scanner driver and the on-screen status display turns off. Scan speed may vary depending on system configuration, interface, software, scan mode settings and document size etc.
- *⁹ Document Size: Max. copy area of 203.2 x 277.3mm (with 16.7mm bottom print margin)
- *¹⁰ Copy speeds are the average of sFCOT and sESAT, ISO / IEC 29183. Copy speed may vary depending on document complexity, copy mode, page coverage, type of paper used etc. and does not take into account warming up time.
- *¹¹ The performance of the printer may be reduced under certain temperature and humidity conditions.
- *¹² For the temperature and humidity conditions of papers such as photo paper, refer to the paper's packaging or the supplied instructions.
- *¹³ When printing ISO / JIS-SCID N2 on 4 x 6" Photo Paper Plus Glossy II using default settings.
- *¹⁴ When copying ISO / JIS-SCID N2 on A4 size plain paper using default settings.

Disclaimer :

- You need to install ink tanks or ink cartridges of all colours whether you perform black and white printing or colour printing. If any one of the ink tanks or ink cartridges is not installed, an error occurs and you cannot perform printing.
- Depending on the paper or the print settings, colour ink may be consumed even when you print a document in black or perform printing in black and white. When any one of the colours of ink has run out, you need to replace the ink tank or ink cartridge.
- When you use the Canon printer for the first time after you install the bundled ink tanks, the printer consumes a small amount of ink in the amount to enable printing by filling the nozzles of the Print Head with ink. For this reason, the number of sheets that can be printed with the first ink tanks is fewer than the succeeding ink tanks.
- The printing costs described in the brochures or websites are based on the consumption data from not the first ink tank / ink cartridge but the succeeding ink tank / ink cartridge.
- To keep printer's performance, Canon printer performs cleaning automatically according to its condition. When the printer performs cleaning, a small amount of ink is consumed. In this case, all colours of ink may be consumed.

[Cleaning function]

The cleaning function helps the printer to suck air bubbles or ink itself from the nozzle and thus prevents print quality degradation or nozzle clogging.

- The repairing parts for printers will be available five years after production is discontinued. Depending on your model, we may ask you to replace it with a new one, or one with almost the same performance as a maintenance service. In this case, it may be that you cannot use supplies or accessories for your model or the compatible OS will be changed.
- The warranty term for free repair varies from country to country and starts from the date of purchase. Free repair does not apply to supplies (paper or ink tanks / cartridges / print head) even within the warranty term.
- To obtain good printing quality, use up ink within six months after opening.
- Regarding a solution to a problem caused by using non-genuine ink cartridges (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), a fee will be charged even within the warranty term. Keep this in your mind when you use non-genuine ink.
- If you use non-genuine ink cartridges (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), they may have a negative effect on the performance of the printer or the printing quality may be reduced. In addition, though it is a rare case and does not present a safety hazard, it is reported that a print head will become heated or smoke will be emitted from it due to an ingredient not contained in genuine Canon ink. (Note that this does not apply to all non-genuine ink.)
- CREATIVE PARK PREMIUM is a premium content service available exclusively to users only when all of the colours of genuine Canon inks are installed.
- A printer with a fax function stores the following fax data in printer's memory:
 - Faxes not printed out due to conditions such as ink running out.
 - Faxes in the send queue.

If you disconnect the power cord, the date and time settings are reset and faxes stored in the printer's memory will be deleted. Before you disconnect the power cord, confirm that faxes you need to keep have already been printed or sent.

- If you will be installing the Canon printer driver on Mac OS X and using the printer through a network connection, you can select [Bonjour] or [canonijnetwork] in the [Add Printer] dialog. If [Bonjour] is selected, remaining ink level messages may differ from those indicated by [canonijnetwork]. [canonijnetwork] is not displayed if the Canon printer driver is not installed. Access our web site through the Internet and download the latest printer driver for your model. Canon recommends you to use [canonijnetwork] for printing.



- **Address** : Office No. D-4, Ambika Darshan Building, Chittabhai Patel Road, Behind Sapan Nikhil Classes, Ahead of Kandivali Bus Depot, Kandivali (E), Mumbai-400101.
- **Phone No**: +022-28460505 (50 lines)
- **Email**: itsolutions@varay.co.in