

## Specifications for PIXMA E400



<b>Printer</b>			
Maximum Printing Resolution	4800 (horizontal)* <sup>1</sup> x 600 (vertical) dpi		
Print Head / Ink	Type:	FINE Cartridge	
	Number of Nozzles:	Total 1,280 nozzles	
	Ink Droplet Size:	2pl	
	Ink Tank:	PG-47, CL-57	
Print Speed* <sup>2</sup> Based on ISO / IEC 24734. Click <a href="#">here</a> for summary report Click <a href="#">here</a> for Document Print and Copy Speed Measurement Conditions	Document: Col	ESAT / Simplex	approx. 4.0ipm
	Document: B / W	ESAT / Simplex	approx. 8.0ipm
Printable Width	Up to 203.2mm (8inch)		
Printable Area	Bordered Printing	Top margin: 3mm, Bottom margin: 16.7mm, Left / Right margin: each 3.4mm (LTR / LGL: Left: 6.4mm, Right: 6.3mm)	
Recommended Printing Area	Top margin: 31.6mm / Bottom margin: 29.2mm		
Paper Size	A4, A5, B5, LTR, LGL, 4 x 6", 5 x 7", Envelopes (DL, COM10), Custom size (width 101.6mm - 215.9mm, length		

	152.4mm - 676mm)	
Paper Handling - Rear Tray: E400 (Maximum Number)	Plain Paper	A4, A5, B5, LTR=60, LGL=10
	Photo Paper Plus Glossy II (PP-201)	4 x 6"=20
	Glossy Photo Paper "Everyday Use" (GP-601)	4 x 6"=20
	Envelope	European DL / US Com. #10=5
Paper Weight	Rear Tray	Plain Paper: 64-105 g/m <sup>2</sup> , Canon specialty paper: max paper weight: approx. 275 g/m <sup>2</sup> (Photo Paper Plus Glossy II (PP-201))
Ink End Sensor	Dot count	
Print Head Alignment	Manual	
<b>Scan</b> * <sup>4</sup>		
Scanner Type	Flatbed	
Scanning Method	CIS (Contact Image Sensor)	
Optical Resolution* <sup>5</sup>	600 x 1200dpi	
Selectable Resolution* <sup>6</sup>	25 - 19200dpi	
Scanning Bit Depth (Input / Output)	Grayscale:	16bits / 8bits
	Colour:	48bits / 24bits (RGB each 16bits / 8bits )
Line Scanning Speed* <sup>7</sup>	Grayscale:	1.2ms/line (300dpi)
	Colour:	3.5ms/line (300dpi)
Scanning Speed* <sup>8</sup>	Reflective: A4 Colour / 300dpi	Approx. 14secs.
Maximum Document Size	Flatbed:	A4 / LTR (216 x 297mm)
<b>Copy</b>		
Maximum Document Size	A4 / LTR (216 x 297mm)	
Compatible Media	Size:	A4, LTR
	Type:	Plain Paper
Image Quality	Plain Paper:	Fast, Standard

Copy Speed* <sup>9</sup> Based on ISO / IEC 24735 and ISO / IEC 29183 standard. Click <a href="#">here</a> for summary report Click <a href="#">here</a> for Document Print and Copy Speed Measurement Conditions	Document: Colour: sFCOT / Simplex:	approx. 30secs.
	Document: Colour: sESAT / Simplex:	Approx. 1.8ipm
Multiple Copy	Black / Colour	1 - 21 pages
<b>System Requirements</b>		
Windows:	(Please visit <a href="http://www.canon-asia.com">www.canon-asia.com</a> to check OS compatibility and to download the latest driver updates.)	Windows 8 / Windows 7 / Windows XP / Windows Vista
Macintosh:		Mac OS X v10.6.8 and later
<b>General Specifications</b>		
Interface	USB 2.0 Hi-Speed	
Operating Environment	Temperature: 15 - 30°C; Humidity: 10 - 80% RH (no dew condensation)	
Storage Environment	Temperature: 0 - 40°C; Humidity: 5 - 95% RH (no dew condensation)	
Acoustic Noise (PC Print)	Photo (4" x 6")* <sup>10</sup>	approx. 46.0dB(A)
<b>Power</b>	AC 100 - 240V, 50 / 60Hz	
Power Consumption	Standby (scanning lamp is off) USB connection to PC	Approx. 1.0W
	OFF:	Approx. 0.4W
	Copying* <sup>11</sup> USB connection to PC	Approx. 9W
Environment	Regulation:	RoHS (EU, China), WEEE (EU)
	Eco-Label:	Energy Star
Dimension (W x D x H)		approx. 426 x 306 x 145mm
Weight		approx. 3.5kg

**Specifications are subject to change without notice. :**

- \*<sup>1</sup> Ink droplets can be placed with a pitch of 1 / 4800 inch at minimum.
- \*<sup>2</sup> Document print speeds are the averages of ESAT in Office Category Test for the default simplex mode, ISO / IEC 24734.  
Photo print speed is based on the default setting using ISO / JIS-SCID N2 on Photo Paper Plus Glossy II and does not take into account data processing time on host computer.  
Print speed may vary depending on system configuration, interface, software, document complexity, print mode, page coverage, type of paper used etc.
- \*<sup>3</sup> Paper types NOT supported for borderless printing are as follows: Envelope, High Resolution Paper, T-Shirt Transfer, Photo Stickers
- \*<sup>4</sup> TWAIN driver (ScanGear) is based on the TWAIN specification V1.9 and requires the Data Source Manager comes with the operating system.
- \*<sup>5</sup> Optical resolution is a measure of maximum hardware sampling resolution, based on ISO 14473 standard.
- \*<sup>6</sup> Increasing the scanning resolution will limit the maximum possible scanning area.
- \*<sup>7</sup> The fastest speed in Hi-Speed USB on Windows PC. Transfer time to computer is not included.
- \*<sup>8</sup> Color document scan speed is measured with ISO / IEC 29183 Target A.  
Scan speed indicates the time measured between pressing the scan button of the scanner driver and the on-screen status display turns off.  
Scan speed may vary depending on system configuration, interface, software, scan mode settings and document size etc.
- \*<sup>9</sup> Copy speeds are the average of sFCOT and sESAT, ISO / IEC 29183.  
Copy speed may vary depending on document complexity, copy mode, page coverage, type of paper used etc. and does not take into account warm-up time.
- \*<sup>10</sup> When printing ISO / JIS-SCID N2 on 4" x 6" Photo Paper Plus Glossy II using default settings.
- \*<sup>11</sup> When printing ISO / JIS-SCID N2 on A4 size plain paper using default settings.

## Disclaimer :

- You need to install ink tanks or ink cartridges of all colours whether you perform black and white printing or colour printing. If any one of the ink tanks or ink cartridges is not installed, an error occurs and you cannot perform printing.
- Depending on the paper or the print settings, colour ink may be consumed even when you print a document in black or perform printing in black and white. When any one of the colours of ink has run out, you need to replace the ink tank or ink cartridge.
- When you use the Canon printer for the first time after you install the bundled ink tanks, the printer consumes a small amount of ink in the amount to enable printing by filling the nozzles of the Print Head with ink. For this reason, the number of sheets that can be printed with the first ink tanks is fewer than the succeeding ink tanks.
- The printing costs described in the brochures or websites are based on the consumption data from not the first ink tank / ink cartridge but the succeeding ink tank / ink cartridge.
- To keep printer's performance, Canon printer performs cleaning automatically according to its condition. When the printer performs cleaning, a small amount of ink is consumed. In this case, all colours of ink may be consumed.

### [Cleaning function]

The cleaning function helps the printer to suck air bubbles or ink itself from the nozzle and thus prevents print quality degradation or nozzle clogging.

- The repairing parts for printers will be available five years after production is discontinued. Depending on your model, we may ask you to replace it with a new one, or one with almost the same performance as a maintenance service. In this case, it may be that you cannot use supplies or accessories for your model or the compatible OS will be changed.
- The warranty term for free repair varies from country to country and starts from the date of purchase. Free repair does not apply to supplies (paper or ink tanks / cartridges / print head) even within the warranty term.
- To obtain good printing quality, use up ink within six months after opening.
- Regarding a solution to a problem caused by using non-genuine ink cartridges (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), a fee will be charged even within the warranty term. Keep this in your mind when you use non-genuine ink.
- If you use non-genuine ink cartridges (including ones supplemented with non-genuine ink by making a hole in the cartridge or so), they may have a negative effect on the performance of the printer or the printing quality may be reduced. In addition, though it is a rare case and does not present a safety hazard, it is reported that a print head will become heated or smoke will be emitted from it due to an ingredient not contained in genuine Canon ink. (Note that this does not apply to all non-genuine ink.)
- CREATIVE PARK PREMIUM is a premium content service available exclusively to users only when all of the colours of genuine Canon inks are installed.
- A printer with a fax function stores the following fax data in printer's memory:
  - Faxes not printed out due to conditions such as ink running out.
  - Faxes in the send queue.

If you disconnect the power cord, the date and time settings are reset and faxes stored in the printer's memory will be deleted. Before you disconnect the power cord, confirm that faxes you need to keep have already been printed or sent.

- If you will be installing the Canon printer driver on Mac OS X and using the printer through a network connection, you can select [Bonjour] or [canonijnetwork] in the [Add Printer] dialog. If [Bonjour] is selected, remaining ink level messages may differ from those indicated by [canonijnetwork]. [canonijnetwork] is not displayed if the Canon printer driver is not installed. Access our web site through the Internet and download the latest printer driver for your model. Canon recommends you to use [canonijnetwork] for printing.



- **Address** : Office No. D-4, Ambika Darshan Building, Chittabhai Patel Road, Behind Sapan Nikhil Classes, Ahead of Kandivali Bus Depot, Kandivali (E), Mumbai-400101.
- **Phone No**: +022-28460505 (50 lines)
- **Email**: [itsolutions@varay.co.in](mailto:itsolutions@varay.co.in)